

9R

5 E

E4-E5

T5N-R28E

T5N-R29E

22 23

27 26

T 10805

T 10463

23 24

26 25

T 2502

T 11726

24 19

25 30

AW

T 10371

T 10370

T 11257

T 10372

T 2493

T 2490

1 15.5

11258 9.8

1 9.3

2 13.5 15.0

T 11091

T 2491

1 1.8 1.5

2 4.0

3 2.9 3.0

2 HEL 128.5 130.8

1 HEL 129.4 129.9

35.1

2 HEL 35.0 NW

3 HEL 33.0 NW

34.4

7 HEL 5.3 NW

27 26

34 35

T 10935

26 25

35 36

25 30

36 31

2 HEL 32.5 32.8

3 HEL 34.8 36.9

1 HEL 61.8 65.4

6 HEL 43.9 41.3

5 HEL 49.0 49.4

104.4

4 HEL 24.5 23.7

7 HEL 21.0 21.2 NW

8 HEL 11.1 11.3 NW

4 HEL 100.2 NW 103.4

5 HEL 98.9 NW 100.4

SEE MAP 6E